



QUICK START GUIDE




1	LINE IN	10	LCD
2	EARPHONE JACK	11	REC
3	SD/MMC CARD SLOT	12	ERASE
4	Internal Microphone	13	A-B/REPEAT
5	MODE	14	EXTERNAL SPEAKER
6	TIMER	15	VOLUME + / -
7	MENU	16	HOLD
8	SPEED	17	RESET
9	LED	18	USB/POWER TERMINAL



Important Information

- 1) Use the supplied USB cable to connect your Radio YourWay LX to your computer. The CD included with your Radio YourWay LX is not required if you are using Windows XP, 2000, or ME. However, if your computer uses Windows 98 you will need to install drivers that are found on the CD.
- 2) If no buttons are pressed within 20 seconds while in a Menu or Timer screen, the Radio YourWay LX will “time out” and return to the opening screen. All recent changes will be lost. For example, if you press the menu button, but you do not select a menu option within 20 seconds your Radio YourWay LX will return to the mode screen it was in prior to the menu button being pressed.
- 3) By default the Radio YourWay LX will turn itself completely off after three minutes if unused.
- 4) **Before you start we recommend formatting the internal memory of the Radio YourWay LX and SD card, if you purchased one:**
 - Turn the Radio YourWay LX on by pressing the ► / ■ (play) button for three seconds.
 - Press the Menu button.
 - Press ▼ (down) and scroll to “INT FORMAT #6” (or for an SD card “EXT FORMAT #7”). Press the ► / ■ (play) button to select.
 - Press ◀◀ (left) to check the YES box.
 - Press ► / ■ (play) to confirm and you’re ready to go!

Charging the Battery



Please fully charge the battery prior to using the Radio YourWay LX. The battery can be charged using the AC adapter, or by connecting it to a PC or MAC with the included USB cable. It takes approximately 4 hours to fully charge the battery using either method.

FULL BATTERY




LOW BATTERY



Setting the Time


- Make sure you always have enough battery power. After 1 or 2 hours of the battery being fully discharged, the year/day/hour settings are all lost and must be set again.
- In order for timer recordings to function properly, the correct time and date must be set. See below for Setting the Date.

Press MENU and select “Time Set” using the ► / ■ (play) button. You will now see a screen similar to the one shown below.



To change the hour and minute use the ▲ (up) and ▼ (down) buttons. To move between the hour and minute fields use the ◀◀ (left) and ▶▶ (right) buttons. Push the ► / ■ (play) button to confirm the date you have set is correct.

Using a Memory Card



When inserting an SD memory card ensure that the card is inserted properly as shown in the diagram (taking note of the correct side up) or you may damage the card and/or external card slot.

By pushing the A-B REPEAT button, you can switch between the internal memory of the Radio YourWay and the SD memory card. The small icon showing “INT” or “SD” located above the month will indicate the current memory mode you are using.



Setting the Date

Press MENU and scroll to “Calendar” using the ▼ (down) button. When “Calendar” is highlighted press ► / ■ (play).

You will now see a screen similar to the one shown below.




To move between the Year/Month/Date fields use the ▲ (up) and ▼ (down) buttons. To change the Year/Month/Date use the ◀◀ (left) and ▶▶ (right) buttons. Push the ► / ■ (play) button to confirm the date you have set is correct.

To exit the MENU screen, press the MENU button.

Switching Modes

There are four modes: "AM", "FM", "MUSIC", and "VOICE". To switch between these, press the MODE button repeatedly.



Voice Recording

Switch to the "MUSIC" mode and press the red REC button. The small red light above the display screen should be lit, indicating that you are now recording. After saying a few words stop the recording by pressing the ► / ■ (play) button. You should now see some numbers scrolling across the display. This represents the recording you just made. To play the file back press ► / ■ (play) button. (You may need to adjust the volume.)

AM Recording

Switch to "AM" mode. (To switch between modes press the MODE button repeatedly.) Press ►► (right) or ◀◀ (left) on the control circle to tune to another frequency. Once you have selected a station, begin recording by pressing the red REC button. The small red light above the display screen should be lit, indicating that you are now recording. When you are finished recording press the ► / ■ (play) button. The recording light should now be off. To replay your AM recording, switch to "MUSIC" mode. A folder icon named AM will now appear on the screen. Highlight the AM folder by pressing ▼ (down). Once highlighted press ►► (right) to open the AM folder. You should now see some numbers scrolling across the display. This represents the recording you just made. To play the file back press ► / ■ (play) button. (You may need to adjust the volume.)

Retrieving Your Recording

The "MUSIC" mode contains all recordings made on the Radio YourWay LX, except for scheduled recordings. If you recorded using a scheduled recording, your file will be found in the "VOICE" mode in a folder titled "SCHEDULE". If you made a manual recording in the "AM" mode, your file will be stored in the "MUSIC" mode in a folder titled "AM". All other types of recordings will be stored in their respective folders (FM recordings will be stored in the "FM" folder, etc ...). To open a folder scroll ▼ (down), highlight the folder you would like to open and press ►► (right). Once the folder is open you will see a line of numbers beginning with a letter and ending with .MP3. This is a recorded file. For example:
A001I05112109432700590.mp3

This is how it is broken down:

- A = AM
- 001 = recording number (#1)
- I05 = year recorded (2005)
- 1121 = date recorded (11/21)
- 094327 = time recording started (9:43 27)
- 00590 = frequency (590)
- . MP3 = format of recording

To play this file press ► / ■ (play).

Timer Recording

You can program the Radio YourWay LX to automatically record your favorite broadcast by using the daily or weekly timer function.

- **Note: You cannot set a timer recording while the unit is playing, recording, or in a menu.**

1. Press and hold the TIMER button for 3 seconds to activate the timer recording screen.

You will now see a screen similar to the one below.



2. Select a "SCHEDULE" slot (1-20) using the ◀◀ (left) or ►► (right) buttons.
3. Move between the different timer setting categories using the ▲ (up) or ▼ (down) buttons.

The first Timer Setting is "TYPE". Use the ▼ (down) button to highlight "TYPE". Now you may modify this setting by pressing ◀◀ (left) or ►► (right) to select either "RECORD", "PLAY" or "DISABLE". After you have made your selection press ▼ (down) to move to the next item.

The next timer setting is "MEMORY". Use the ►► (right) button to toggle between "INTERNAL" and "EXTERNAL" memory. Press the ▼ (down) button to move to the next item.

- **Note: If you choose the "EXTERNAL" memory option and no external memory card is inserted, you will get a message saying "NOT INSERTED CARD".**

The next timer setting is "DATE SET". This setting will indicate what day or days you would like the recording to begin. Use the ◀◀ (left) or ►► (right) buttons to select "WEEK" or "DATE". "DATE" is only used to set a specific date in the future for a one-time recording. The most common setting used to record radio shows is "WEEK" because the unit will automatically record every week on the day or days you specify.

This is the procedure if you select "WEEK":

Press ▼ (down) and highlight "WEEK". Select "MON-FRI" or "MONDAY", "TUESDAY", "WEDNESDAY", "THURSDAY", "FRIDAY", "SATURDAY" or "SUNDAY" using ◀◀ (left) or ►► (right) buttons. Press the ▼ (down) button to move to the next timer setting.

- **Note: If you want to record on more than one day other than "MON-FRI" (for example: "MONDAY", "WEDNESDAY" and "FRIDAY") you will need to schedule a recording for each day.**

This is the procedure if you select "DATE":

Press ▼ (down) and highlight "DATE". Select the month using the ◀◀ (left) or ►► (right) buttons. Move to the day field by pressing the ▼ (down) button. Select the day you would like to record by using the ◀◀ (left) or ►► (right) buttons. Once you set the month and day press the ▼ (down) button to move to the next timer setting.

The next timer setting is "SOURCE". Use the ►► (right) button to choose between "AM", "FM", "MIC" or "LINE" setting. Use the ▼ (down) button to move to the next timer setting.

If “AM” or “FM” is selected, the next timer setting will be “FREQ”. Use ◀ (left) or ▶ (right) buttons to select a preset station, or you may manually select a station by pressing the ▼ (down) button again and then ◀◀ (left) or ▶▶ (right) buttons to change frequency. Press the ▼ (down) button to move to the next timer setting.

The next timer setting is “BITRATE”. This determines the quality of the recording. The higher the quality, the more space in the memory it will require. By pressing ▶▶ (right) you can adjust the setting to: 32, 64, 96, 128, 192 or 256. 32 is recommended for AM recordings, 64 for FM recordings, and 128 for CD recordings. Press the ▼ (down) button to move to the next item.

The next timer setting is “START”. This is the time your recording will start. By pressing the ◀◀ (left) or ▶▶ (right) buttons you can modify the hour of day the recording will start. Always be aware of the AM or PM setting in front of the hour. To switch between AM and PM keep cycling the hour setting. Press the ▼ (down) button to move to the minutes setting. The minutes can be modified by pressing the ◀◀ (left) or ▶▶ (right) buttons. When finished with this setting, press the ▼ (down) button to move to the next item.

The next timer setting is “END”. By pressing the ◀◀ (left) or ▶▶ (right) buttons you can modify the hour of day at which the recording will end. Always be aware of the AM or PM setting in front of the hour. To switch between AM and PM keep cycling the hour setting. Press the ▼ (down) button to move to the minutes setting. The minutes can be modified by pressing the ◀◀ (left) or ▶▶ (right) buttons.

When finished, press the ▶ / ■ (play) button. You will receive the following message: “DATA SAVED? Yes or No.” Select “YES” by pressing ▶▶ (left) followed by the ▶ / ■ (play) button to confirm. You are now finished setting a timer recording.

To view a saved timer recording, press (don’t hold) the TIMER button one time and use ◀◀ (left) or ▶▶ (right) buttons to view more setting information.

Podcasting

Podcasting allows you to subscribe to feeds, which include links to audio programs. Every time one of your subscriptions posts a new program, it will automatically download onto your computer. You can then transfer those shows to a portable music device (such as your Radio YourWay LX), listen to it throughout your house via a wireless connection and take it with you wherever you go. Essentially, it’s a personalized radio station that you can program and change whenever you want.

If you’re interested in using your Radio YourWay LX for listening to Podcasts, we suggest you begin by visiting the following websites:

<http://en.wikipedia.org/wiki/Podcast> – Provides an excellent overview of the history and terms involved in podcasting.

<http://www.ipodder.org/> – Here, you will find the software you need to subscribe to podcasts. Click on the “Download iPodder” link, choose your operating system (Windows, Mac, Linux, etc ...), and download the software. There are several “aggregator” programs to choose from, but we recommend iPodder. It’s free, easy to use, and works with any computer.

<http://www.podshow.com/> – Podshow.com is just one of the websites that lists different programs that are available for podcast.

You might also be interested in <http://www.kyouradio.com/>

Once you have downloaded your podcasting software (aggregator) and subscribed to a few podcasts, you can drag and drop your podcasts into your Radio YourWay LX

Important

If you are using a computer to drag and drop files onto a 1 GIG SD card, always make a folder for the new files. If this is not done, the external memory card’s capacity may be reduced by half.

Firmware Upgrades

The latest firmware can be downloaded from <http://www.pogoproducts.com/pogoftp.html>

1. Connect the Radio YourWay LX to your computer using the included USB cable.
2. Unzip the file, then save it to the internal memory of the unit.
3. After transferring the file, disconnect the USB cable.
4. The Radio YourWay LX will automatically try to upgrade the firmware. It automatically detects its firmware version. If your Radio YourWay LX already has a newer version of firmware, the upgrade (in this case downgrade) will not take place. If the unit is not operating properly, please format the current firmware before trying to upgrade it.

Reset

If the unit is not operating properly, please RESET the unit by pushing the RESET button (found on the right side of the unit) gently with a thin object for 1 second. Please do not push the RESET button using a sharp object. The unit will retain all previously programmed information and files.

Hard Reset

This special method of resetting will erase all internal files, system settings, and timer settings.

Slide the HOLD switch up (it’s located below the VOLUME switch). Press and hold the ERASE button. While pressing the ERASE button, insert a thin object (toothpick or paperclip) into the RESET hole (found on the right side of the unit) for 1 second (You should feel it click). **Continue pressing the ERASE button for 15 seconds.** After 15 seconds a message will say: “Formatting, Please Wait.” When the message disappears, slide the HOLD switch to the down position. Your Radio YourWay LX is ready to use.